


Timex Computer TC2068 Edge Connector



GND	32B	32A	BLUE
BRIGHT	31B	31A	GREEN
CSYNC	30B	30A	RED
A11	29B	29A	NOT USED
A9	28B	28A	A10
<u>BUSAK</u>	27B	27A	A8
<u>ROMCS</u>	26B	26A	<u>RFSH</u>
A4	25B	25A	<u>M1</u>
A5	24B	24A	NOT USED
A6	23B	23A	NOT USED
A7	22B	22A	<u>WAIT</u>
<u>RESET</u>	21B	21A	NOT USED
<u>BUSREQ</u>	20B	20A	<u>WR</u>
NOT USED	19B	19A	<u>RD</u>
NOT USED	18B	18A	<u>IORQ</u>
NOT USED	17B	17A	<u>MREQ</u>
VIDEO	16B	16A	<u>HALT</u>
GND	15B	15A	<u>NMI</u>
NOT USED	14B	14A	<u>INT</u>
A3	13B	13A	D4
A2	12B	12A	D3
A1	11B	11A	D5
A0	10B	10A	D6
CLK	9B	9A	D2
GND	8B	8A	D1
GND	7B	7A	D0
SLOT	6B	6A	SLOT
+9V	5B	5A	NOT USED
+5V	4B	4A	D7
A12	3B	3A	A13
A14	2B	2A	A15
<u>BE</u>	1B	1A	EXROM